

EZ-Load™ Pipettor Heads

The EZ-Load pipettor heads from Apricot Designs simplify the use of disposable tips for multiple channel pipetting by making tip loading and unloading a simple manual process without the requirement for any tools.



The EZ-Load heads are used in conjunction with specially-made disposable pipette tip racks that allow the transfer of a rack of tips directly from the package into the EZ-Load head. The operator simply drops the rack of tips into the head, places the head in the pipettor, and presses a button to load the head.



The EZ-Load heads feature a Swing Lock design that allows the tips to be placed into the head without any contact on the bottom part of the tips, thus eliminating cross-contamination due to contact with the head after pipetting. The tops of the pipette tips are sealed against the face seal by the pipettor's automatic electric loading mechanism. A reliable seal is provided for optimal pipetting performance.

EZ-Load heads are compatible with Apricot Designs 550 and ESP disposable tips. Optional inserts can be installed to allow easy loading of tips for serial dilution operations by row or column.

4 easy steps to load disposable tips and start pipetting!



Remove tips from package rack



Place tips in EZ-Load head



Load head into pipettor



Press the Load/Unload button

Ordering Information

Part Number	Description	Compatible Tips	Compatible Pipettors
096-A-01-EZL-550	EZ-Load Pipetting Head, 96-channel	Apricot 550	PP-96H-M series, i-Pipette96-500 series
096-A-01-EZL-SL-550	EZ-Load Pipetting Head, Swing Lock Design, 96-channel	Apricot 550	PP-96H-M series, i-Pipette96-500 series
096-A-01-EZL-ESP	EZ-Load Pipetting Head, 96-channel	Apricot ESP	PP-96L-M series, i-Pipette96-125 series
096-A-01-EZL-SL-ESP	EZ-Load Pipetting Head, Swing Lock Design, 96-channel	Apricot ESP	PP-96L-M series, i-Pipette96-125 series
384-A-01-EZL	EZ-Load Pipetting Head, 384-channel	Apricot ESP	PP-384-M, i-Pipette384 series
384-A-01-EZL-SL	EZ-Load Pipetting Head, Swing Lock Design, 384-channel	Apricot ESP	PP-384-M, i-Pipette384 series
384-A-01-EZL-096	EZ-Load Pipetting Head, 96-channel (Offset)	Apricot ESP	PP-384-M, i-Pipette384 series
384-A-01-EZL-SL-096	EZ-Load Pipetting Head, Swing Lock Design, 96-channel (Offset)	Apricot ESP	PP-384-M, i-Pipette384 series